


# BTP-2002NP RECEIPT PRINTER Feed Button Program Guide

---


## ***Parameter Setting (Configuring) by Key-strokes***

- 1) Hold the FEED button pressed while switching the printer on.
- 2) After the printer has printed the configuration sheet, **press and hold the FEED button to configure the printer. The main menu for the key-stroke setting procedure is printed.**
- 3) The procedure consists of several sub-menus and step-by-step working is needed.
- 4) With every choice is a number. This number indicates the number of times the FEED button has to be shortly pressed. After this, the choice is validated by an additional, but longer press of the FEED button (1 sec).
- 5) After all settings have been done, they are stored in the printer by stepping back through the submenus to the main menu by using the number “1” plus additional press for validation.


## ***Parameter Setting by Key-strokes***




## ***Setting Configuration of the Printer***




## Configuration of the Serial Interface




## Setting Mechanism and Hardware



## Print Setting



## Paper Near-end Sensor Setting



## Set Default Configuration

